



00 00 134 776	T/M COUNTERSHAFT THIRD SPEED GEAR (28T.)
00 00 134 779	T/M FOURTH SPEED GEAR (23-22T.)
00 00 134 930	T/M THIRD SPEED GEAR (31-26T.)
00 00 138 836	T/M SECOND SPEED GEAR (36-26T.)
00 00 161 073	T/M SECOND AND THIRD SPEED SYNCHRONIZER ASSEMBLY (26 SPLINES)
00 00 161 075	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER ASSEMBLY (22-22T.)
00 00 163 476	T/M THIRD AND FOURTH SPEED SYNCHRONIZER ASSEMBLY (29-29T.)
00 00 163 477	T/M FIRST AND SECOND SPEED SYNCHRONIZER ASSEMBLY (32 SPLINES)
00 00 164 974	T/M COUNTERSHAFT (12-20-29-37 T.)
00 00 165 526	T/M MAIN DRIVE GEAR (18-22T.)
00 00 166 695	T/M FIFTH SPEED SYNCHRONIZER CONE (45-24T.)
00 00 167 404	POWER TAKE OFF SHAFT ASSEMBLY (12-17T.)
00 00 894 200	T/M FOURTH SPEED GEAR (48T.)
00 01 119 100	T/M MAINSHAFT
00 01 119 130	T/M OVERDRIVE SYNCHRONIZER BLOCKING RING
00 01 119 328	T/M SYNCHRONIZER CONE (51T.)
00 01 119 330	T/M OIL SEAL RING 85X105X12
00 01 120 467	T/M DRIVE GEAR (58T.)
00 01 120 471	T/M COUNTERSHAFT FIRST SPEED GEAR (35T.)
00 01 120 472	T/M COUNTERSHAFT DRIVE GEAR (62T.)
00 01 125 451	T/M AUXILIARY DRIVE GEAR KIT (42-18T.)
00 01 131 972	T/M SECOND SPEED GEAR (38-30T.)
00 01 131 982	T/M REVERSE GEAR (44-23T.)
00 01 132 111	T/M GASKET KIT
00 01 141 336	T/M COUNTERSHAFT THIRD SPEED GEAR (28T.)
00 02 624 513	T/M FOURTH SPEED GEAR (33-19T.)
00 02 640 845	T/M PLANETARY REDUCTION CARRIER COUPLING FLANGE (34 SPLINES)
00 03 205 042	T/M COUNTERSHAFT (12-15T.)
00 03 205 081	T/M REVERSE IDLER GEAR SHAFT
00 03 205 082	T/M MAINSHAFT
00 03 205 083	T/M COUNTERSHAFT (12-15T.)
00 03 205 121	T/M OVERDRIVE INTERMEDIATE SHAFT WITH GEAR (19-19-30T.)
00 03 205 212	T/M COUNTERSHAFT (12-17T.)
00 03 205 220	T/M OVERDRIVE INTERMEDIATE SHAFT WITH GEAR (25-19-30T.)
00 03 205 223	T/M MAIN DRIVE GEAR (34-18T.)
00 03 205 225	T/M REVERSE IDLER GEAR SHAFT
00 03 205 226	T/M MAINSHAFT
00 03 205 233	T/M OVERDRIVE MAIN DRIVE GEAR (30T.)
00 03 205 268	T/M PLANETARY REDUCTION CARRIER
00 03 205 269	T/M PLANETARY REDUCTION GEAR SHAFT
00 03 205 279	T/M GEAR SHIFT FORK SHAFT
00 03 205 291	T/M MAIN DRIVE GEAR (34-18T.)
00 03 205 297	T/M PLANETARY REDUCTION GEAR SHAFT
00 03 205 317	T/M MAIN DRIVE GEAR (29-19T.)
00 03 208 310	T/M FIRST AND SECOND SPEED SYNCHRONIZER BLOCKING RING
00 03 208 484	T/M FIRST AND SECOND SPEED SYNCHRONIZER BLOCKING RING
00 03 208 484*	T/M FIRST AND SECOND SPEED SYNCHRONIZER BLOCKING RING
00 03 211 441	T/M THIRD AND FOURTH SPEED SYNCHRONIZER SLIDING COLLAR (22T.)
00 03 211 476	T/M SHIFT FORK SLIDING BLOCK (BRONZE)
00 03 211 556	T/M GEAR SHIFT CONTROL ROD LEVER
00 03 215 953	T/M MAIN DRIVE GEAR OIL PUMP



00 03 216 304	T/M FOURTH SPEED GEAR SLEEVE
00 03 216 305	T/M REVERSE GEAR SLEEVE
00 03 216 307	T/M SELECTOR SHAFT BUSHING
00 03 216 335	T/M FIFTH SPEED GEAR SLEEVE
00 03 216 338	T/M FIRST SPEED GEAR SLEEVE
00 03 216 376	T/M PLANETARY REDUCTION GEAR SHAFT ELASTIC PIN
00 03 217 411	T/M COUNTERSHAFT THIRD AND FOURTH SPEED GEAR (23-28T.)
00 03 217 412	T/M COUNTERSHAFT FIFTH SPEED GEAR (34T.)
00 03 217 417	T/M FIFTH SPEED GEAR (24-19T.)
00 03 217 418	T/M FOURTH SPEED GEAR (29-22T.)
00 03 217 420	T/M THIRD SPEED GEAR (35-22T.)
00 03 217 421	T/M SECOND SPEED GEAR (42-27T.)
00 03 217 422	T/M FIRST AND SECOND SPEED SYNCHRONIZER HUB
00 03 217 424	T/M REVERSE GEAR (47-26T.)
00 03 217 425	T/M OVERDRIVE DRIVE GEAR (31-25T.)
00 03 217 426	T/M OVERDRIVE COUNTERSHAFT CONNECTING GEAR (54T.)
00 03 217 431	T/M REVERSE IDLER GEAR (21T.)
00 03 217 434	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER SLIDING COLLAR (18T.)
00 03 217 437	T/M SYNCHRONIZER SLIDING COLLAR (22T.)
00 03 217 439	T/M THIRD AND FOURTH SPEED SYNCHRONIZER HUB (22T.)
00 03 217 440	T/M SYNCHRONIZER SLIDING COLLAR (22T.)
00 03 217 441	T/M REVERSE GEAR (45-22T.)
00 03 217 471	T/M FIRST AND SECOND SPEED SYNCHRONIZER SLIDING COLLAR (27T.)
00 03 217 555	T/M FIRST AND SECOND SPEED SYNCHRONIZER HUB
00 03 217 556	T/M SYNCHRONIZER HUB
00 03 217 562	T/M SECOND SPEED GEAR (36-27T.)
00 03 217 566	T/M REVERSE IDLER GEAR (21T.)
00 03 217 567	T/M FIRST AND SECOND SPEED SYNCHRONIZER SLIDING COLLAR (27T.)
00 03 217 568	T/M REVERSE GEAR THRUST WASHER (26T.)
00 03 217 569	T/M THIRD AND FOURTH SPEED SYNCHRONIZER SLIDING COLLAR (22T.)
00 03 217 570	T/M FIFTH AND SIXTH SPEED SYNCHRONIZER SLIDING COLLAR (19T.)
00 03 217 573	T/M OVERDRIVE SYNCHRONIZER CONE (48T.)
00 03 217 576	T/M OVERDRIVE SYNCHRONIZER CONE (48T.)
00 03 217 579	T/M FIFTH SPEED GEAR (22-19T.)
00 03 217 584	T/M OVERDRIVE SYNCHRONIZER HUB
00 03 217 604	T/M COUNTERSHAFT FIFTH SPEED GEAR (43T.)
00 03 217 624	T/M COUNTERSHAFT THIRD AND FOURTH SPEED GEAR (22-27T.)
00 03 217 625	T/M COUNTERSHAFT FIFTH SPEED GEAR (36T.)
00 03 217 626	T/M THIRD SPEED GEAR (32-22T.)
00 03 217 627	T/M FIFTH SPEED GEAR (24-19T.)
00 03 217 628	T/M FOURTH SPEED GEAR (26-22T.)
00 03 217 629	T/M OVERDRIVE DRIVE GEAR (25-25T.)
00 03 217 632	T/M COUNTERSHAFT THIRD AND FOURTH SPEED GEAR (22-29T.)
00 03 217 634	T/M COUNTERSHAFT FIFTH SPEED GEAR (42T.)
00 03 217 640	T/M FOURTH SPEED GEAR (26-22T.)
00 03 217 651	T/M FIRST SPEED GEAR (50-27T.)
00 03 217 676	T/M THIRD AND FOURTH SPEED SYNCHRONIZER HUB
00 03 217 710	T/M OVERDRIVE SYNCHRONIZER SLIDING COLLAR (48T.)
00 03 217 713	T/M SYNCHRONIZER BLOCKING RING
00 03 217 749	T/M COUNTERSHAFT SIXTH SPEED GEAR (41T.)
00 03 217 753	T/M COUNTERSHAFT SIXTH SPEED GEAR (37T.)



00 03 217 760	T/M THIRD SPEED GEAR (22-18T.)
00 03 217 762	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER CONE (36T.)
00 03 217 763	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER SLIDING COLLAR (36T.)
00 03 217 771	T/M COUNTERSHAFT SIXTH SPEED GEAR (53T.)
00 03 217 794	T/M THIRD AND FOURTH SPEED SYNCHRONIZER HUB (51T.)
00 03 217 795	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER CONE (51T.)
00 03 217 796	T/M FIRST AND SECOND SPEED SYNCHRONIZER HUB
00 03 217 797	T/M FIRST AND SECOND SPEED SYNCHRONIZER HUB
00 03 217 819	T/M COUNTERSHAFT FIFTH SPEED GEAR (61T.)
00 03 217 820	T/M COUNTERSHAFT THIRD AND FOURTH SPEED GEAR (23-33T.)
00 03 217 821	T/M COUNTERSHAFT SIXTH SPEED GEAR (48T.)
00 03 217 822	T/M SYNCHRONIZER SLIDING COLLAR (19T.)
00 03 217 823	T/M FIFTH SPEED GEAR (26-19T.)
00 03 217 824	T/M FOURTH SPEED GEAR (30-22T.)
00 03 217 825	T/M THIRD SPEED GEAR (34-22T.)
00 03 217 827	T/M FIRST AND SECOND SPEED SYNCHRONIZER HUB
00 03 221 107	T/M MAINSHAFT NUT
00 03 222 503	T/M OIL SEAL RING 24X29
00 03 222 570	T/M MAIN DRIVE GEAR GASKET
00 03 223 332	T/M SYNCHRONIZER CONE (51T.)
00 03 223 335	T/M FIRST AND SECOND SPEED SYNCHRONIZER SLIDING COLLAR (63T.)
00 03 223 343	T/M SYNCHRONIZER CONE (51T.)
00 03 223 344	T/M FIRST AND SECOND SPEED SYNCHRONIZER CONE (63T.)
00 03 226 100	T/M PLANETARY REDUCTION SYNCHRONIZER PRESSURE SPRING, OUTER
00 03 226 101	T/M PLANETARY REDUCTION SYNCHRONIZER PRESSURE SPRING, INNER
00 03 226 149	T/M SYNCHRONIZER PRESSURE SPRING
00 03 229 676	T/M SHIFT FORK SWING SCREW
00 03 461 117	T/M MAIN DRIVE GEAR BEARING RETAINER
00 03 461 313	T/M MAINSHAFT GEAR SPACER
00 03 461 328	T/M AUXILIARY MAINSHAFT BUSHING
00 03 461 333	T/M FIRST SPEED GEAR (36T.)
00 03 461 335	T/M AUXILIARY MAINSHAFT LOW SPEED GEAR SPACER
00 03 461 506	T/M MAINSHAFT GEAR WASHER
00 03 461 508	T/M MAINSHAFT GEAR WASHER
00 03 461 514	T/M AUXILIARY MAINSHAFT REDUCTION GEAR WASHER
00 03 461 515	T/M AUXILIARY MAINSHAFT REDUCTION GEAR WASHER
00 03 461 517	T/M AUXILIARY MAINSHAFT LOW GEAR SPACER
00 03 461 521	T/M AUXILIARY MAINSHAFT LOW GEAR WASHER
00 03 461 700	T/M MAIN DRIVE GEAR (18T.)
00 03 461 705	T/M DRIVE GEAR (28T.)
00 03 461 707	T/M MAINSHAFT SLIDING CLUTCH (18-18T.)
00 03 461 711	T/M LOW SPEED GEAR (44T.)
00 03 461 714	T/M MAINSHAFT SLIDING CLUTCH (18-18T.)
00 03 461 715	T/M FOURTH SPEED GEAR (34T.)
00 03 461 716	T/M THIRD SPEED GEAR (38T.)
00 03 461 717	T/M SECOND SPEED GEAR (38T.)
00 03 461 718	T/M FIRST SPEED GEAR (44T.)
00 03 461 719	T/M MAINSHAFT REVERSE GEAR (46T.)
00 03 461 724	T/M COUNTERSHAFT FIRST SPEED GEAR (22T.)
00 03 461 725	T/M COUNTERSHAFT SECOND SPEED GEAR (30T.)
00 03 461 726	T/M COUNTERSHAFT THIRD SPEED GEAR (40T.)



00 03 461 729	T/M COUNTERSHAFT DRIVE GEAR (36T.)
00 03 461 731	T/M COUNTERSHAFT SECOND SPEED GEAR (22T.)
00 03 461 732	T/M COUNTERSHAFT THIRD SPEED GEAR (30T.)
00 03 461 733	T/M COUNTERSHAFT FOURTH SPEED GEAR (36T.)
00 03 461 736	T/M COUNTERSHAFT DRIVE GEAR (40T.)
00 03 461 739	T/M REVERSE IDLER GEAR (27T.)
00 03 461 742	T/M SYNCHRONIZER PLATE AND PIN ASSEMBLY
00 03 461 744	T/M SYNCHRONIZER PLATE AND PIN ASSEMBLY
00 03 461 745	T/M AUXILIARY SLIDING CLUTCH (18-18T.)
00 03 461 746	T/M AUXILIARY MAINSHAFT SHIFT COUPLING (18T.)
00 03 461 747	T/M AUXILIARY MAINSHAFT SLIDING CLUTCH GEAR (20-20T.)
00 03 461 749	T/M AUXILIARY MAINSHAFT GEAR (32T.)
00 03 461 750	T/M AUXILIARY DRIVE GEAR (28T.)
00 03 461 752	T/M AUXILIARY COUNTERSHAFT WITH GEARS ASSEMBLY (35-14-38T.)
00 03 461 753	T/M AUXILIARY SLIDING CLUTCH (18-18T.)
00 03 461 762	T/M AUXILIARY OUTPUT SHAFT QUILL KIT
00 03 461 903	T/M SECOND AND THIRD SPEED SHIFT FORK
00 03 461 910	T/M SECOND AND THIRD SPEED SHIFT FORK
00 03 461 911	T/M FOURTH AND FIFTH SPEED SHIFT FORK
00 03 461 916	T/M SPLITTED GEAR SHIFTING FORK
AJ 18 443 003	T/M COVER GASKET 22X27
00 22 887 200	T/M GEAR SHIFTING FORK
00 22 887 300	T/M AUXILIARY MAINSHAFT SLIDING CLUTCH GEAR (20-20T.)
00 22 889 000	T/M AUXILIARY MAINSHAFT REDUCTION GEAR WASHER
00 22 891 300	T/M SHIFT FORK
00 22 892 600	T/M MAINSHAFT SLIDING CLUTCH (18-18T.)
00 22 892 700	T/M MAINSHAFT GEAR WASHER
00 22 892 900	T/M MAINSHAFT GEAR WASHER
00 22 893 300	T/M MAINSHAFT GEAR SPACER
00 22 893 700	T/M FIRST SPEED GEAR (44T.)
00 22 893 800	T/M MAINSHAFT REVERSE GEAR (46T.)
00 22 894 000	T/M MAINSHAFT
00 22 894 100	T/M COUNTERSHAFT FOURTH SPEED GEAR (69T.)
00 22 894 500	T/M AUXILIARY DRIVE GEAR KIT (40-18T.)
00 22 895 600	T/M AUXILIARY DRIVE GEAR KIT (42-18T.)
00 22 897 500	T/M AUXILIARY MAINSHAFT REDUCTION GEAR WASHER
00 23 511 392	T/M FIRST SPEED GEAR (39-18T.)
00 23 511 397	T/M REVERSE GEAR (35-18T)
00 23 511 802	T/M MAINSHAFT
00 23 876 034	DIFF. BEARING ADJUSTER L.H. (20T.)
00 23 876 035	DIFF. PINION GEAR THRUST WASHER
00 23 876 039	DIFF. SIDE GEAR THRUST WASHER
00 23 876 046	DIFF. IDLER PINION PIN
00 23 876 069	DIFF. SIDE GEAR L.H. (18T.-16 SPLINES)
00 23 876 071	DIFF. SIDE GEAR (18T.-33 SPLINES)
00 23 876 075	DIFF. SPIDER
00 23 876 083	DIFF. HIGH SPEED CLUTCH PLATE THRUST WASHER
00 23 876 097	DIFF. POWER DIVIDER HELICAL AND SIDE GEAR WASHER
00 24 477 132	T/M OIL SEAL RING 25X35X7/10
00 34 613 748	T/M AUXILIARY OUTPUT SHAFT QUILL
00 63 087 800	T/M THIRD AND FOURTH SPEED SHIFT FORK



00 63 087 900	T/M AUXILIARY SHIFT FORK
00 63 095 800	T/M DRIVE GEAR (34T.)
00 63 096 400	T/M FIRST SPEED GEAR (38T.)
00 63 096 500	T/M CLUTCH SHAFT BUSHING
00 63 098 100	T/M MAINSHAFT GEAR SPACER
00 63 098 200	T/M MAINSHAFT SLIDING CLUTCH (18-18T.)
00 63 099 100	T/M SECOND SPEED GEAR (38T.)
00 63 099 200	T/M THIRD SPEED GEAR (28T.)
00 63 099 500	T/M REVERSE GEAR (46T.)
00 63 099 800	T/M AUXILIARY OUTPUT SHAFT WASHER
03 21 440 800	T/M PLANETARY REDUCTION SYNCHRONIZER SLIDING COLLAR (63T.)
04 48 701 313	T/M SYNCHRONIZER PLATE AND PIN ASSEMBLY
08 55 335 000	POWER TAKE OFF GASKET 12X15,5
50 00 203 893	T/M PLANETARY REDUCTION RING GEAR (85T.)
50 00 240 130	T/M OVERDRIVE SYNCHRONIZER HUB
50 00 240 195	T/M SYNCHRONIZER BLOCKING RING
50 00 240 204	T/M OVERDRIVE SYNCHRONIZER BLOCKING RING
50 00 240 205	T/M OVERDRIVE SYNCHRONIZER SLIDING COLLAR (48T.)
50 00 240 234	T/M SHIFT FORK SWING SCREW
50 00 240 237	T/M SHIFT FORK SWING SCREW
50 00 240 259	T/M OIL SEAL RING 25X35X7
50 00 240 266	T/M GEAR SHIFT LEVER SHAFT
50 00 240 306	T/M REVERSE IDLER GEAR THRUST WASHER
50 00 240 308	T/M OUTPUT FLANGE RETAINER PLATE
50 00 240 396	T/M MAIN DRIVE GEAR OIL PUMP
50 00 240 401	T/M COUNTERSHAFT SECOND AND THIRD SPEED GEAR (20-24T.)
50 00 240 409	T/M SECOND SPEED GEAR (42-22T.)
50 00 240 410	T/M FIRST AND SECOND SPEED SYNCHRONIZER HUB (22T.)
50 00 240 411	T/M SYNCHRONIZER SLIDING COLLAR (22T.)
50 00 240 416	T/M THIRD SPEED GEAR (37-22T.)
50 00 240 417	T/M FOURTH SPEED GEAR SLEEVE
50 00 240 419	T/M THIRD SPEED GEAR (36-18T.)
50 00 240 420	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER HUB
50 00 240 422	T/M MAINSHAFT NUT
50 00 240 429	T/M REVERSE GEAR SLEEVE
50 00 240 439	T/M GASKET
50 00 240 456	T/M GASKET
50 00 240 465	BALL BEARING (45X85X19 MM)
50 00 240 493	T/M FIRST AND SECOND SPEED SYNCHRONIZER BLOCKING RING
50 00 240 495	T/M PLANETARY REDUCTION SYNCHRONIZER PRESSURE SPRING, OUTER
50 00 240 501	T/M PLANETARY REDUCTION SYNCHRONIZER PRESSURE PLUNGER
50 00 240 517	T/M PLANETARY REDUCTION SHIFT FORK SHAFT
50 00 240 534	T/M GASKET
50 00 240 877	T/M AUXILIARY SLIDING CLUTCH (18-18T.)
50 00 241 118	T/M GEAR SHIFTING FORK
50 00 241 443	T/M MAINSHAFT GEAR WASHER
50 00 241 444	T/M MAINSHAFT GEAR WASHER
50 00 241 448	T/M MAINSHAFT
50 00 241 449	T/M MAIN DRIVE GEAR BEARING NUT
50 00 241 595	T/M SYNCHRONIZER BLOCKING RING
50 00 241 600	T/M SYNCHRONIZER PRESSURE PLUNGER





50 00 241 909	T/M OVERDRIVE SYNCHRONIZER BLOCKING RING
50 00 241 937	T/M MAIN DRIVE GEAR BEARING SPLIT RING
50 00 241 941	T/M MAIN DRIVE GEAR BEARING SECURING RING
50 00 242 005	T/M OVERDRIVE DRIVE GEAR (31-25T.)
50 00 242 253	T/M GEAR SHIFT FORK SHAFT
50 00 242 324	T/M MAIN DRIVE GEAR (25-19T.)
50 00 242 325	T/M COUNTERSHAFT THIRD AND FOURTH SPEED GEAR (23-28T.)
50 00 242 326	T/M COUNTERSHAFT FIFTH SPEED GEAR (34T.)
50 00 242 327	T/M COUNTERSHAFT SIXTH SPEED GEAR (53T.)
50 00 242 329	T/M FIFTH SPEED GEAR (24-19T.)
50 00 242 330	T/M FOURTH SPEED GEAR (29-22T.)
50 00 242 332	T/M THIRD SPEED GEAR (35-22T.)
50 00 242 333	T/M FIRST SPEED GEAR (51-27T.)
50 00 242 637	T/M DRIVE GEAR (28T.)
50 00 242 640	T/M MAINSHAFT GEAR (32T.)
50 00 242 641	T/M THIRD SPEED GEAR (36T.)
50 00 242 642	T/M SECOND SPEED GEAR (40T.)
50 00 242 643	T/M FIRST SPEED GEAR (44T.)
50 00 242 644	T/M MAINSHAFT REVERSE GEAR (42T.)
50 00 242 650	T/M COUNTERSHAFT DRIVE GEAR (40T.)
50 00 242 687	T/M AUXILIARY MAINSHAFT BUSHING
50 00 242 790	T/M COUNTERSHAFT SIXTH SPEED GEAR (41T.)
50 00 242 830	NEEDLE BEARING (33X47X20)
50 00 242 847	T/M THIRD SPEED GEAR (22-18T.)
50 00 242 852	T/M SECOND SPEED GEAR (28-18T.)
50 00 242 853	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER CONE (36T.)
50 00 242 854	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER SLIDING COLLAR (36T.)
50 00 242 857	T/M SYNCHRONIZER PRESSURE SPRING
50 00 242 858	T/M SYNCHRONIZER PRESSURE PLUNGER
50 00 242 859	T/M SYNCHRONIZER FOLLOWER
50 00 242 991	T/M REVERSE IDLER GEAR (20T.)
50 00 243 754	T/M COVER GASKET
50 00 250 058	T/M SYNCHRONIZER PRESSURE PLUNGER
50 00 250 081	T/M OVERDRIVE INTERMEDIATE SHAFT WITH GEAR (19-19-30T.)
50 00 255 275	T/M SYNCHRONIZER PRESSURE SPRING, OUTER
50 00 255 276	T/M SYNCHRONIZER PRESSURE PLUNGER
50 00 255 277	T/M SYNCHRONIZER PRESSURE SPRING, INNER
50 00 255 957	T/M COVER GASKET
50 00 257 146	T/M REVERSE IDLER GEAR THRUST WASHER
50 00 275 036	T/M COUNTERSHAFT THIRD AND FOURTH SPEED GEAR (22-29T.)
50 00 275 037	T/M FIFTH AND SIXTH SPEED SYNCHRONIZER SLIDING COLLAR (19T.)
50 00 275 040	T/M MAIN DRIVE GEAR BEARING RETAINER
50 00 275 437	T/M MAINSHAFT NUT
50 00 283 805	T/M COUNTERSHAFT (16T.)
50 00 283 821	T/M REVERSE IDLER GEAR SHAFT
50 00 283 828	T/M MAINSHAFT
50 00 283 829	T/M FIRST AND SECOND SPEED SYNCHRONIZER HUB (22T.)
50 00 283 830	T/M SYNCHRONIZER SLIDING COLLAR (22T.)
50 00 283 831	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER HUB
50 00 283 832	T/M FOURTH AND FIFTH SPEED SYNCHRONIZER SLIDING COLLAR (18T.)
50 00 283 833	T/M MAINSHAFT NUT



































