



(KIT-R9)	DIFF. GEAR REPAIR KIT
(KIT-S9)	DIFF. GEAR REPAIR KIT
(1324/GASKET KIT)	T/M GASKET KIT
(1324/GASKET M1)	T/M REPAIR GASKET KIT
0070 214 002	DIFF. GEAR AND PINION (6-37)
0070 214 051	DIFF. GEAR AND PINION (6-35)
0070 314 143	T/M COUNTERSHAFT (17-27-31-36-41-16T.)
0091 304 109	T/M SYNCHRONIZER CONE (57T.)
0091 304 201	T/M SYNCHRONIZER SLIDING COLLAR (51T.)
0091 304 310	T/M SYNCHRONIZER CONE (57T.)
0091 304 311	T/M SYNCHRONIZER CONE (57T.)
0095 353 232	FRONT WHEEL PLANET GEAR (34T.)
0501 209 014	FUEL PIPE KIT
0501 209 015	FUEL PIPE KIT
0501 209 448	FUEL PIPE KIT
0501 209 449	FUEL PIPE KIT
0501 211 275	FUEL PIPE KIT
0501 211 276	FUEL PIPE KIT
0501 211 399	FUEL PIPE KIT
0501 211 400	FUEL PIPE KIT
0501 304 692	T/M PLANETARY REDUCTION GEAR THRUST WASHER
0501 305 887	T/M PLANETARY REDUCTION GEAR THRUST WASHER
0501 306 212	T/M PLANETARY REDUCTION GEAR THRUST WASHER
0501 306 439	T/M OIL SEAL RING 25X28X14,2
0501 307 769	T/M OIL SEAL RING
0501 310 614	T/M VALVE GASKET
0501 312 738	T/M OIL SEAL RING 30X37X4
0501 313 513	T/M GASKET
0501 314 060	T/M MAIN DRIVE GEAR DIAPHRAGM
0501 314 108	T/M SYNCHRONIZER OIL RING
0501 314 246	T/M COVER GASKET
0501 314 587	T/M COVER GASKET
0501 314 747	T/M COVER GASKET
0501 314 808	T/M GASKET
0501 315 085	SPEEDOMETER COVER GASKET
0501 316 146	T/M GASKET
0501 317 240	T/M COVER GASKET
0501 317 536	T/M OIL SEAL RING 105X98X2,90
0501 318 308	T/M COVER GASKET
0501 321 065	T/M GASKET
0501 322 828	T/M GASKET
0501 322 829	T/M GASKET
0501 324 626	T/M GASKET
0630 501 024	T/M MAINSHAFT BEARING CIRCLIP
0630 501 031	T/M COUNTERSHAFT FIFTH SPEED GEAR SNAP RING
0630 501 033	T/M COUNTERSHAFT FOURTH SPEED GEAR SNAP RING
0630 502 027	T/M MAIN DRIVE GEAR LOCK RING
0630 502 063	T/M MAIN DRIVE GEAR LOCK RING
0630 531 055	POWER TAKE OFF SHAFT LOCK RING
0631 329 016	T/M PLANETARY REDUCTION GEAR SHAFT ELASTIC PIN
0631 329 017	T/M PLANETARY REDUCTION PLANET GEAR SHAFT ELASTIC PIN



0631 329 048	T/M PLANETARY REDUCTION GEAR SHAFT ELASTIC PIN
0631 329 050	T/M PLANETARY REDUCTION PLANET GEAR SHAFT ELASTIC PIN
0634 300 020	T/M OIL SEAL RING 25X32X5
0634 300 185	T/M OIL SEAL RING 10X15X3
0634 300 302	T/M OIL SEAL RING 25X35X7
0634 300 712	T/M OIL SEAL RING 85X105X12
0634 304 327	T/M VALVE O-RING 5,8X1,78
0634 307 367	T/M OIL SEAL RING 25X35X7/10
0634 307 825	T/M OIL SEAL RING 53X63X16,2
0634 312 523	T/M OIL SEAL RING 25X33X7/4,5
0634 313 018	T/M O/RING 82X3
0634 313 052	POWER TAKE OFF O-RING 68X4
0634 313 053	T/M O-RING 72X4
0634 313 198	T/M O/RING 20X3
0634 313 293	T/M O/RING 28X3
0634 313 320	T/M O/RING 67X3
0634 313 375	T/M OIL SEAL RING 105X98X2,90
0634 313 505	T/M O/RING 42X3
0634 313 671	T/M O-RING 80X3
0634 313 734	T/M O-RING 94X3
0634 313 805	T/M O/RING 82X4
0634 314 015	POWER TAKE OFF O-RING 68X4
0634 314 017	T/M VALVE O-RING 5,8X1,78
0634 314 018	T/M VALVE O-RING 59X2
0634 314 019	T/M O-RING 94X3
0634 314 020	T/M O-RING 8X2
0634 314 021	T/M O-RING 36,2X3
0634 314 022	T/M O-RING 72X4
0634 316 057	T/M O-RING 36,2X3
0634 316 174	T/M O-RING 8X2
0634 801 013	T/M COVER GASKET 10X14
0634 801 027	T/M GASKET
0634 801 028	T/M COVER GASKET
0634 801 045	T/M COVER GASKET 16X22
0634 801 050	T/M COVER GASKET 16X22
0634 801 062	T/M COVER GASKET 18X24
0634 801 074	T/M COVER GASKET 22X27
0634 801 097	T/M GASKET 30X36
0634 801 156	T/M COVER GASKET
0634 801 164	POWER TAKE OFF GASKET 12X15,5
0634 801 203	T/M GASKET 16X22
0634 801 205	POWER TAKE OFF GASKET 12X15,5
0634 801 206	T/M GASKET 24X29
0634 801 217	SEALING RING 14X20
0634 801 219	T/M GASKET 16X22
0634 801 236	T/M OIL SEAL RING 24X29
0634 801 246	T/M GASKET
0634 801 249	T/M GASKET 26X31
0634 801 250	T/M GASKET
0634 801 260	T/M GASKET
0634 801 321	T/M GASKET 38X48



0634 801 324	T/M COVER GASKET
0635 304 904	BALL BEARING (90X160X30)
0635 331 390	BALL BEARING 45X75X16 MM
0635 332 057	BALL BEARING (65X120X23)
0635 332 156	BALL BEARING (45X85X19 MM)
0635 376 023	TAPERED ROLLER BEARING (40X80X32)
0635 460 010	T/M SYNCHRONIZER LOCK BALL
0730 000 833	T/M GEAR SHIFT SELECTOR ARM BEARING RETAINING RING
0730 008 055	T/M GASKET 10X14
0730 008 056	T/M GASKET 12X17
0730 008 057	T/M GASKET 14X18
0730 008 637	T/M OIL SEAL RING 24X29
0730 009 515	T/M GASKET 22X27
0730 061 816	T/M MAIN DRIVE GEAR OIL PUMP SPACER RING
0730 061 890	T/M MAIN DRIVE GEAR OIL PUMP SPACER RING
0730 061 921	T/M OVERDRIVE SYNCHRONIZER HUB SECURING RING
0730 062 579	T/M MAIN DRIVE GEAR RETAINING RING
0730 101 784	DIFF. SIDE GEAR THRUST WASHER
0730 102 629	T/M MAIN DRIVE GEAR BEARING SPLIT RING
0730 102 954	T/M MAIN DRIVE GEAR BEARING SPLIT RING
0730 102 958	T/M MAIN DRIVE GEAR BEARING SPLIT RING
0730 102 988	DIFF. PINION GEAR THRUST WASHER
0730 102 989	T/M MAIN DRIVE GEAR BEARING SPLIT RING
0730 103 102	T/M PLANETARY REDUCTION GEAR SPACER RING
0730 103 367	T/M MAIN DRIVE GEAR SPLIT RING (2 PCS.)
0730 103 510	T/M MAIN DRIVE GEAR BEARING SPLIT RING
0730 103 846	T/M PLANETARY REDUCTION GEAR SPACER RING
0730 150 064	T/M REVERSE IDLER GEAR THRUST WASHER
0730 160 344	T/M FIRST SPEED GEAR SLEEVE
0730 260 330	T/M SELECTOR SHAFT BUSHING
0730 260 528	T/M SELECTOR SHAFT BUSHING
0730 361 046	T/M MAIN DRIVE GEAR BEARING SECURING RING
0731 208 137	T/M GEAR SHIFT PIN
0731 208 138	T/M GEAR SHIFT PIN
0732 040 385	T/M SYNCHRONIZER PRESSURE SPRING, OUTER
0732 040 386	T/M SYNCHRONIZER PRESSURE SPRING, INNER
0732 040 409	T/M SYNCHRONIZER PRESSURE SPRING
0732 040 497	T/M SYNCHRONIZER PRESSURE SPRING
0732 040 736	T/M PLANETARY REDUCTION SYNCHRONIZER PRESSURE SPRING, OUTER
0732 040 929	T/M PLANETARY REDUCTION SYNCHRONIZER PRESSURE SPRING, INNER
0732 041 571	T/M SYNCHRONIZER PRESSURE SPRING
0732 042 510	T/M SYNCHRONIZER PRESSURE SPRING
0734 300 093	T/M OIL SEAL RING 85X105X12
0734 300 196	T/M OIL SEAL RING 25X35X7
0734 303 046	T/M O/RING 59X3
0734 307 280	OIL SEAL RING
0734 307 294	OIL SEAL RING
0734 309 376	T/M OIL SEAL RING 28X42X11
0734 310 104	T/M OIL SEAL RING 52X68X8
0734 310 108	T/M OIL SEAL RING 48X69X10
0734 310 109	T/M OIL SEAL RING 85X105X10

